

Digitizing **MiniDV Tapes** using Canon Camcorder and Elgato Video Capture

Table of Contents

I. Equipment	2
II. Getting Started	2
III. Setting Up Elgato Video Capture	7
III.I. Get Started	7
III.II. Connect Video	9
III.III. Connect Audio	
IV. Record	
V. Trim	
VI. Finish Up	

I. Equipment

This digitization project requires the following equipment (borrow at CCC desk):

- Canon ZR65 Camcorder (includes 3.5 mm to RCA AV cable and power cord)
- Elgato Video Capture device
 Headphones

II. Getting Started

Log in to the Digitization on Demand computer. You can log in with your library card or a guest pass.

Open the grey terminal cover on the front left of the camera.






Plug the Black 3.5mm end of the RCA AV cable into the AV jack on the camcorder.



Plug the other end of the RCA cables into the Elgato Video Capture device.

Plug the USB end of the Elgato Video Capture device directly into the computer.

Please do not use a USB hub. Elgato requires a direct connection.





Plug in the Camcorder power cord at both ends.

The DC (tube) end goes into the **DC-IN 8.4V** terminal on the camera.





Turn the camcorder **On** by pressing down on the green button on the **power dial** and rotating it to point at **PLAY (VCR).**

To insert your MiniDV tape into the camcorder, use the **OPEN/EJECT** switch on the bottom of the camcorder.





Pull the tab toward **EJECT.** The cassette compartment cover will open.

When it is fully opened, it will **ding.**



Press the **PUSH** mark on the cassette compartment.

Wait while your tape fully retracts before closing the compartment cover.





III. Setting Up Elgato Video Capture

III.I. Get Started


Open the Elgato Video Capture application on the computer.			
The application will guide you through the video digitization process. Follow the prompts on the screen.			
📑 Elgato Video Capture	x		
video capture A Get Started	Record video from a VCR, DVR, set-top box, camcorder or any other analog video source to watch and share on your PC. Play your captured video in Windows Media Player or add it to iTunes to sync with an iPod, iPhone or Apple TV. You can also upload the video directly into your YouTube account, or edit it right away in Windows Live Movie Maker.		
Connect Video Connect Audio Record Trim Finish Up	What is the name of this movie? Digitization is Fun! Approximately how long is the movie? 60 Minutes 30 Minutes 90 Minutes 120 Minutes 120 Minutes 120 Minutes 120 Minutes 120 Minutes 120 Minutes 120 Minutes	Name your movie and select the approximate length of the movie.	
elgato 🧷 🛈	Go Back Preferences Continue		
elgato 🏾 🕐 🛈	Go Back Preferences Continue	Before you continue, you can click Preferences to adjust the settings of your project.	



Preferences X	
General Video Audio	
Save movies in: Videos	
G: > C: > WVML > Videos	
High Resolution (Needs a fast PC)	
Preserve Source Format	In Preferences , you
Automatically check for Updates	can toggle between
	General, Video, and
OK Cancel	Audio settings to personalize your
Preferences X	digitization project.
General Video Audio	
Brightness: 0	Find definitions of
Contrast: 0	Video and Audio terms in the
Saturation: 0	Glossary.
Hue: 0	
Default	You can also change
Derault	your preferences after you have
OK Cancel	recorded your
Preferences ×	movie.
General Video Audio	
Gain: 0 dB	Once you are satisfied with your
Gain:	settings, click OK .
	5,
OK Cancel	
	In the original Elgato
	window, click
elgato ⑦ ① Go Back Preferences Continue	Continue.




III.II. Connect Video



III.III. Connect Audio


Before continuing, check that:


- Your headphones are plugged in to the computer
- The computer system sound is on and the volume is at an audible level
 - o To check, click the volume symbol ∽ on the bottom right of the Task Bar





IV. Record






Once you would like to stop the recording, you can click the red **Stop Recording** button.

If you had checked the box to automatically stop the recording, it will stop on its own.



V. Trim

This is an optional step. If you do not wish to trim your recording, you may click **Continue**.



VI. Finish Up

Your movie will automatically save in the file location you chose in **Preferences**. By default, this is the **Videos** folder on the PC. 📑 Elgato Video Capture × Elgato will give you a few Your movie was saved successfully: video capture Arm 🏪 C: 🕨 🚞 Users 🕨 🧮 WVML 🕨 💽 Videos 🕨 🎆 Digitization is Funl.mp4 default options for what What would you like to do next? to do with your digitized movie. Get Started 0 Play with Windows Media Player Connect Video Add to Windows Media Player Library If you would like to Connect Audio Record create a new recording, Add to iTunes click Again and the Finish Up application will restart Edit with Windows Live Movie Maker from the beginning. You Tube Upload to YouTube If you are finished recording, click Quit. elgato () () Again Preferences Quit Videos × + You will find your final \leftarrow \rightarrow \uparrow \bigcirc \bigcirc \checkmark Videos \rightarrow a Search Videos scans in File O New → → □ New → □ View → ····
 O □ □ ▲ ○ □ ↑↓ Sort → □ View → ····
 O □ □ ↓ Sort → □ View → ····
 O □ □ ↓ Sort → 📑 Details A Home **Explorer I** in the 🔁 Gallery OneDrive - Personal folder you chose in 🛄 Desktop Captures EVC_Temp Preferences. Downloads Documents Pictures 🕖 Music 📔 Videos If you did not choose a > 🔷 OneDrive folder, it will be in 🗸 💻 This PC > Local Disk (C) Videos. Copy it to your USB storage device or save it to a cloud storage service. 3 iten